

Community Water Quality Monitoring Procedure

Bilingual review copy: English and isiZulu. Human language approval required.

English	isiZulu
Community Water Quality Monitoring Procedure	Inqubo Yokugapha Ikhwalithi Yamanzi Okuphuza Emphakathini
Purpose: This procedure explains how field teams collect and record drinking water samples so that results are reliable and traceable to the correct site.	Inhloso: Le nqubo ichaza ukuthi amaqembu asemkhakheni awaqoqa futhi awarekhoda kanjani amasampula amanzi okuphuza ukuze imiphumela ithembeke futhi ilandeleke endaweni efanele.
Scope: It applies to routine samples collected from reservoirs, treatment outlets, and public taps. The procedure does not cover emergency chemical spills or laboratory instrument calibration.	Ububanzi: Isebenza kumasampula avamile aqoqwa emadamu, ezindaweni zokukhipha amanzi okwelashwa, nasempompini zomphakathi. Le nqubo ayihlanganisi ukuvuza kwamakhemikhali okuphuthumayo noma ukulinganisa amathuluzi aselabhorethri.
Responsibilities: The team leader checks that each technician has PBT, clean sample bottles, and a calibrated meter. Technicians are responsible for completing the Chain of Custody Form QMS-07 and reporting unsafe conditions.	Izemfanelo: Umholi weqembu uhlola ukuthi uchwepheshe ngamunye une-PBT, amabhodlela amasampula ahlanzekile, nemitha elinganisiwe. Ochwepheshe banomthwalo wemfanelo wokuqedela Ifomu Lokulandelelwa Kokutholakala Kwezinto (QMS-07) nokubika izimo ezingaphephile.
Procedure: Before collecting a sample, allow the tap to run for 2 minutes. Rinse the probe with clean water, but do not rinse a sterile microbiological bottle. Record pH and turbidity in NTU at the site. Samples must be placed in a cooler between 2 and 8 degrees Celsius.	Inqubo: Ngaphambi kokuqoqa isampula, vumela impompi igijime imizuzu emi-2. Geza iphrobu ngamanzi ahlanzekile, kodwa ungagezi ibhodlela elinyumba elingenawo amagciwane. Bhala i-pH nokufiphala (turbidity) nge-NTU endaweni. Amasampula kufanele abekwe esiqandisini phakathi kuka-2 no-8 degrees Celsius.
Data recording: Write the site code, date, time, and sampler initials on both the bottle and QMS-07. Corrections must be made with a single line through the error; correction fluid is not allowed. The reason for any missing reading must be stated.	Ukurekhoda idatha: Bhala ikhodi yendawo, usuku, isikhathi, nama-inishiyali zomuntu othatha isampula kubhodlela naku-QMS-07. Ukulungisa amaphutha kufanele kwenziwe ngomugqa owodwa phezu kwephutha; ukusebenzisa uketshezi lokulungisa akukuvunyelwe. Isizathu sanoma yikuphi ukungafundi okungekho kufanele sishiwo.
Escalation: If pH is below 6.5 or above 9.5, or	Ukuphakamisa udaba: Uma i-pH ingaphansi

turbidity is higher than 1 NTU, phone the team leader immediately. Do not tell the community that the water is safe or unsafe until the authorised official has reviewed the result.

kuka-6.5 noma ingaphezu kuka-9.5, noma ukufiphala kuphakeme kuno-1 NTU, shayela umholi weqembu ngokushesha. Ungatsheli umphakathi ukuthi amanzi aphephile noma awaphephile kuze kube yilapho isikhulu esigunyaziwe sibuyekeze umphumela.